

Visto[™] INSTALLATION GUIDE • PARTS





*Applicable to all Vista Panel shapes

PACK INCLUDES









Visto[™] Installation Guide • Ceiling Fixture*



*Applicable to all Vista Panel shapes

1. ASER METHOD .L



Lay supplied stencil on ground directly below ceiling surface you would like to install your Vista panel.

Point laser vertically on each marked spot on the stencil while the second person marks the laser spots on the ceiling using a ladder. Apply this method to each attachment spot.


MANUAL METHOD:



Hold stencil to ceiling, marking all fitment locations on ceiling.

If unable to use stencil, use measurements marked on stencil and manually measure and transfer markings.

2.




Insert supplied screws* into adjustment 1 and screw into ceiling at marked spots.

*Use appropriate anchor depending on ceiling material.


Visto[™] Installation Guide • Suspended Fix*



*Applicable to all Vista Panel shapes




Screw adjustment 4 to base, rear of panel, until fixed tightly.




Thread wire a few inches through Adjustment 3. Insert wire through adjustment 4. Screw both adjustments till tight.

1.A.



Apply this to all fitment spots.

2.A.



Apply this to all fitment spots. Adjust all wires to the desired height using accurate measuring*

*Recommended distance from ceiling: 250mm

$Vista^{*}$ installation guide •



*Applicable to all Vista Panel shapes




Using responsible safety measures, lift to designated spot using

two people.

Screw all of adjustment 2 into all of adjustment 1 to ceiling.

Attach opposite corners first then move on to the rest.



Adjust wire length if needed. Enjoy your finished Vista Panel